CAMBRIDGE SYSTEMATICS



TransCAD and the BCAG Model

presented to Caltrans District 3 presented by Cambridge Systematics, Inc. Xuan Liu

September 18th of 2017



- TransCAD Overview and Navigation
- Formatting and Viewing Data
- Data Tables and Joining Data
- Printing Maps using Layouts
- Looking at BCAG Highway Assignment
- Roadway Network Editing
- Advanced Topics?




TransCAD Software Overview

- Transportation data management and analysis
- GIS based transportation planning analysis
- TransCAD:
 - » Let you store, retrieve, analyze, and visualize geographic data in new and useful ways
 - » Has tools to apply sophisticated transportation, operations research, and statistical models.
 - » GISDK (development computer programming language)
- Version & build
 - » Version I have open: Version 7.0 Build 12215 64-bit
 - » 64-bit vs. 32-bit




TransCAD User Interface

TransCAD (Licensed to Cambridge Systematics) - [Map1 - Master_Network]	
🚮 File Edit Map Dataview Selection Tools Procedures Window Help	- 8 X
🚺 📴 🖶 🚔 Master_Network 💿 🔹 🦗 📔 🌌 💥 👭 📔 🎬 💥 🧩 🕷 🗐 🥰 🥵 📰 🛱 🦻 💷 🌞 🖉 🧔 🕲 🖉 👘 🔳 💽 🏹 🛛	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
To T	
	Display Manager ×
	🗷 🛛 🤕 🛩 Endpoints 🔺
	🗎 🖉 🛞 📥 Master_Network
1 miles	
The set	
All a president and a second a seco	
Y Y St Mar	
Et & Marman	
A CALLER AND A CALL	
- AFFER BARSHONS	
- CHARLE AND LONG AND	
	-
THE ALL ALL ALL ALL ALL ALL ALL ALL ALL AL	E by f gt
	· 33
	3.疑
Map scale: 1 Inch = 8.39375 Miles (1:531,828)	
4	CAMBRIDGE SYSTEMATICS





Tr	ransCA	D (Lice	nsed to Cam	nbridge Syst	ematics)					
File	Edit	Map	Dataview	Selection	Tools	Procedures	Networks/Paths	Route Systems	Planning	Transit
i D	🖻 🕻		🎭 abmload	l_byr	•	📰 🖬 🔀	m 🚩 💥 🔆) 🏂 🗐 🐇	3 🕣 💾	🗱 💋



GISDK toolbox

🌬 🗰 🐖 🧕 👯 | Flags

Drawing toolbox*



* For objects on the map – not for geographic editing


Usually docked at the bottom of the window



TransCAD Software Overview

Built-In Forecasting Tools

- » 4-Step Travel Model
- » Model Calibration/Estimation Utilities
- » GIS-Based Roadway and Transit Data
- » Intermediate Results Analysis
- » Matrix Editor
- » Spatial Analysis Tools



Built In Interface

Provides an interactive method of running a Travel Model

> Multi-Mod Line Layer Network File

> > Method 0-D Matrix

> > Class Infor Matrice

✓ EE ✓ EE_TF

Delay Fund Name Capacity Alpha Beta Preload

- Very flexible, but can be a bit tedious to use
- Is enhanced through use of customized "Add-Ins"

					Options				×
					Theme - Crea Max V/ From	ate Theme C 1.8	Interval Siz	ie 0.25	OK Cancel
				l	-Select Li	nk/Zone/	Analysis]
					∏ Sele	et Link/Z	one Queries		uery File
al M	ulti-Class	Assignn	nent					\mathbf{x}	<u> </u>
WA	ATS_Network				Settin	igs [)ptions OK		~
C:\	L\Output\V	alidation1	2\ini_N	etwork.nel		N	letwork Cancel		
Use	er Equilibrium			- Delay	Function	Bureau of F	Public Roads (BPR)	-	
AM	Period Vehicl	e Trips in	OD F •	- -	oll Matrix				
natio				_	1			NOT	
s	PCE	PCE 6	VOT	Fixed Toll	Roa	ad Toll	Exclusion Set		e Fields
	None	1.00	1.00	n/a	n/a		None		iteration
	None	1.00	1.00	n/a	n/a		None	Choos	e Fields
	None	1.00	1.00	n/a	n/a				-
К	None	1.00	1.00	n/a	n/a		None	·	
							>		
tion	Parameters								
		Field				Value	^	riod (sec)	505.00
		[AB_CA	P / BA	_CAP]		n/a			
		ALPHA				0.15			
		BETA			-	4			
		None				0	>		
20		Conve	-	e 0.0100		Path I	Diff 0.001		

Batch Mode

Settings from the interface can be saved

With looping, repetitive tasks can be automated (e.g., run assignment 5 times with different input data but mostly similar settings)


	Batch Mode Toolbox 🛛 🛛 🔀	
Batch Editor	💿 🔳 📑 🐝 🛛 No Run 💌	×
<pre>Opts = null Opts.Input.Database = "C:\\OCTAM_Training\\Output Opts.Input.Network = "C:\\OCTAM_Training\\Output Opts.Input.(IOD Matrix Currency] = {"C:\\OCTAM_Try Opts.Input.[Exclusion Link Sets] = {, , , , , } Opts.Field.[Turn Attributes] = {, , , , , } Opts.Field.[Vehicle Classes] = {1, 2, 3, 4, 5, 6] Opts.Field.[Fixed Toll Fields] = {"N/a", "n/a", " Opts.Field.[Fixed Toll Fields] = {"N/a", "n/a", " Opts.Field.[ICE Fields] = {"None", "None", "None" Opts.Field.[Load Mathcol] = "FFTIME", "[AB_CA] Opts.Global.[Load Mathcol] = 1</pre>	□ Post Process	
Opts.Global.[N Conjugate] = 2 Opts.Global.Convergence = 0.0001		Rename Copy
Opts.Global.Iterations = 100		
Opts.Global.[Number of Classes] = 6		New Delete
Opts.Global.[Class PCEs] = {1, 1, 1, 1, 1, 1}		Move Up Move Down
Opts.Global.[Class VOIs] = {1, 1, 1, 1, 1, 1}		Save Load
Opts.Global.[VDF DLL] = "C:\\Program Files\\Trans	CAD 6.0\\bpr.vdf"	Add to Model Choose Macro
$Opts.Global.[VDF Defaults] = \{, , 0.15, 4, 0\}$		Add to Model Choose Macro
Opts.Output.[Flow Table] = "C:\\Documents and Set	ings\\smcatee\\My Documents\\Caliper\\TransCAD 6.0\\MMA_LinkFlow.bin"	
ret_value = RunMacro("TCB Run Procedure", "MMA",)pts, &Ret)	



Customized Interfaces

- Created with the GISDK scripting language
- Utilize Batch Mode to automate tasks
- Utilize customized code to streamline and customize model processes
- Makes running and analyzing scenarios easy and efficient

Scenario	Folder	Date	Steps
2014 Model	C:\Projects\D3\BCAG\2014\	Friday May 29 2015 (10:00	Trip Generation Create Scen Network
2040 Model	C:\Training\CalTrans\BCAG_Mc	Thu Oct 01 2015 (15:50:33	Network Initialization
			Network Skimming Daily Trip Distribution
			Peak Pr Trip Distributic AM/MD Traffic Assignr
			Feedback Loop
Scenarios Input	Files Output Files		
Description			
2014 Base Year	viodei	Сору	
		elete	
	Sort	by Date	
	Sort	by Name	
	Sort	by Name	



Open Architecture

- Allows for inclusion of any amount or type of data
- Requires deliberate and careful definition of input data requirements
- Almost any aggregate travel model algorithm that can be thought up can be implemented in TransCAD

	Dataview1 ·	Maste	er_Network																- 9 🗙
-	- ID	Dir	Length Road_Name	FUNC_CLASS	AB_TTf	BA_TTf	CAPACITY	CONST_YEAR	B_SPEED BA	SPEED	AB_LANES B	A_LANES	M_CAPFAC	MD_CAPFAC	M_CAPFAC	P_CAPFAC	AB_TIME	BA_TIME A	AB_CONGTT BA_C A
	1	0	0.63 LARKIN RD	Arterial	1.00	1.00	800	2014	50.00	50.00	1	1	2.90	4.85	3.70	7.50	0.75	0.75	- =
	2	0	0.47 ORD FERRY RD	Collector	1.00	1.00	700	2014	45.00	45.00	1	1	2.90	4.85	3.70	7.50	0.63	0.63	-
	3	0	1.14 CHICO RIVER RD	Collector	1.00	1.00	700	2014	45.00	45.00	1	1	2.90	4.85	3.70	7.50	1.52	1.52	-
	4	0	0.73 DURHAM PENTZ RD	Collector	1.00	1.00	700	2014	35.00	35.00	1	1	2.90	4.85	3.70	7.50	1.25	1.25	-
	5	0	4.82 CENTERVILLE RD	Local	1.00	1.00	600	2014	5.00	5.00	1	1	2.90	4.85	3.70	7.50	57.79	57.79	-
	6	0	1.13 BLOCK RD	Local	1.00	1.00	600	2014	25.00	25.00	1	1	2.90	4.85	3.70	7.50	2.71	2.71	-
	7	0	0.11 BELL RD	Local	1.00	1.00	600	2014	35.00	35.00	1	1	2.90	4.85	3.70	7.50	0.19	0.19	-
	8	0	1.65 ROAD 48	Local	1.00	1.00	600	2014	35.00	35.00	1	1	2.90	4.85	3.70	7.50	2.83	2.83	-
	9	0	2.86 RIVER RD	Collector	1.00	1.00	700	2014	35.00	35.00	1	1	2.90	4.85	3.70	7.50	4.90	4.90	-
	10	0	1.49 RIVER RD	Collector	1.00	1.00	700	2014	45.00	45.00	1	1	2.90	4.85	3.70	7.50	1.99	1.99	-
	11	0	2.39 ORD FERRY RD	Collector	1.00	1.00	700	2014	45.00	45.00	1	1	2.90	4.85	3.70	7.50	3.19	3.19	-
	12	0	4.46 SEVEN MILE LN	Local	1.00	1.00	600	2014	45.00	45.00	1	1	2.90	4.85	3.70	7.50	5.95	5.95	-
	13	0	1.88 SEVEN MILE LN	Local	1.00	1.00	600	2014	45.00	45.00	1	1	2.90	4.85	3.70	7.50	2.51	2.51	-
	14	0	1.05 ORD FERRY RD	Collector	1.00	1.00	700	2014	45.00	45.00	1	1	2.90	4.85	3.70	7.50	1.39	1.39	-




Compatible File Formats

- TransCAD can read and write data to/from many universally accepted file formats.
 - » GIS (Shapefile, Geodatabase)
 - » Spreadsheet
 - » Database
 - » Text
 - » HTML (with add-in)
 - » Traffic Software (with add-in)
 - » Others



GIS Applications

- Use TransCAD model results in ArcGIS to create high quality maps.
- Link TransCAD networks to GIS-based analysis tools.



TransCAD Tips



File and Data Types

Data Files actually contain information:

- » Tables (.bin, .DBF)
- » Geographic Files or Layers (.dbd, .shp)
- » Matrices (.mtx)



S. D. Start

File and Data Types

Some files do not contain information:

- » Dataviews (.dvw)
- » Maps (.map) and workspaces (.wrk)
- » Matrix Views (.mvw)

These files refer to other file types that contain data

» Same concept as a project file (.mxd) in ArcMAP

Never use File \rightarrow Save As \rightarrow "Dataview (.dvw)" or "Map (.map)" to save a copy for modification!



ST(


File and Data Types

- Geographic Files (.dbd) are GIS layers and can be edited and viewed.
 - » We use line layers as "roadway networks"
- Route Systems (.rts) contain transit information
 - Route systems are linked to line layers
- Routable Network Files (.net, .tnw) are routable networks used internally by TransCAD.
 - » Routable network files must be created before running certain tasks.
 - » Separate networks for roadway and transit



Useful Features

- Saved Workspaces
- Undo and Redo
- Copy and Paste directly between TransCAD and other programs (e.g., Excel)
- The Display Manager
 - » Show it from Map → Display Manager
- Multiple selection sets
- Many more...





New in TransCAD 6.0, 7.0

- Read and write directly to ESRI Geodatabases
- Improved Mapping Features
 - » Label customization
 - » Transparency
- Under the Hood
 - » 64-bit architecture
 - » More multithreading
 - » New procedures (e.g., drive egress to transit)

TransCAD 7

- » Even More multithreading
- » Improved transit management
- » Improved elevation data
- » Pivot tables and charts



Map Basics: Visualizing



Working with Layers

- Start by opening a map <u>or</u> a geographic (dbd) layer file
 - » Opening a layer will create a new map and add the layer
 - » Opening a map will load all saved layers, settings, etc.
- Access layers with the layers dialog box (

Layers				×	
Layers in Order of Display	Sample	Status			
Endpoints	er	Hidden	*	Close	
Master_Network					
				Hide Layer	
				Add Layer	
				Drop Layer	
				Move Up	
				Move Down	
			~		
Style Labels	Auto	scale Rena	ame	Metadata	
Geographic File C:\CAG\	2014\Outp	uts\Networks\R	oads_Loa	ded_2014.DBD	



Working with Layers


- The Layers Dialog (\Longrightarrow)


		Status Hidden Close	Hide/show a layer
	Master_network	Hide Layer	
		Add Laver Drop Layer	Add/Drop layers
		Move Up	
	Style Labels Autosci Geographic File C/CAG\2014\Outputs		Re-order layers
/	//		
Change a layer style	Add/edit labels	Automatically show/hide layers as certain scales	



Working with Layers


Layers are drawn from TOP to BOTTOM





Display Manager

- \rightarrow Activate from Map \rightarrow Display Manager
- Quick access to layers, settings, etc.
 - » Right-click for more settings, including make working layer



CAMBRIDGE SYSTEMATIC

Color Theme



Creating Maps

- Create a new map by opening a Geographic File (*.dbd)
- Add more layers if desired
 - » 🛃 then 🛛 Add Layer
- Choose the active layer
 - » Use the dropdown selector
 - » Or use the display manager

File	Edit	N	Лар	Dat	aview	Selection	Tools	Procedure
					TAZ_t1			- 💷 🖬
1	۳.	ъ	T	₹ f s	TAZ_t1 16r16p	lin lu		o 🖸
	Map1	L - ~	iz49		101100	_iiriks-	2	

- Change the "default" styles for the layers
- Hide or show layers
 - » 🚘 or the display manager



Color and Pattern Themes

- Set feature colors and styles based on attributes
 - » Color Themes () are often used to display facility type on a roadway network
 - » Pattern Themes (Map → Pattern Theme...) is sometimes used to display number of lanes on a roadway network



Color and Pattern Themes

The Settings Tab

	(Layer: 16r16p_links)
General	\frown
Field	[Road Type]
Metho	d List of Values 2 Load
Max Classe	s 512 3 • Recalculate
	es below or above
	reat zeros as missing values
√ R	ound off the values in each class
Ir Ir	clude counts in legend
ОК	Cancel Apply Remove Customize

- 1. Choose a field to represent
- 2. Choose a method to create categories and number of classes
- * Use the Load and Save buttons to store and recall settings
 - This is a huge time-saver!



Color and Pattern Themes


The Styles Tab

Color Theme (Layer: 16r16p_links)	23
Settings Styles	
Choose a class	
Other St	e
🗌 🦲 Centroid Connector	
Copy P	attern
HOT Interstate	Text
HOV Other	
HOV - Interstate	
HOV - Limited Access	
HOV Interstate	
Legend Text	
Centroid Connector 2	
Color Sets	
<< Previous Next >> Swap Start and End	
From to via	_
OK Cancel Apply Remove Cu	stomize

- 1. Choose a style for each class
- 2. Select a legend text for each class
- 3. Choose from predefined color settings if desired



Functional Class



* Based on BCAG model link layer attribute table



Practice 1: Create a color theme for line layer based on function class


- 1. Open the BCAG Network File (BCAG_Network_2014.dbd)
 - ✓ File → Open, then in the file type dropdown next to 'File name:' select Geographic File(*.cdf,.*dbd) option
 - Browse to the location/folder where the geographic file is located and select the 'BCAG_Network_2014.dbd' and click 'Open' button
- 2. On the top ribbon, click
- it is called 'color theme map wizard'
- 3. It opens up a dialog box with two tabs. In the first tab 'Settings' tab:
 - Select the Func_class from the 'Field' drop down options
 - Select the 'List of Values' from the 'Method' drop down options
 - ✓ Max. Classes: Use the default value (512)
- 4. Go to the 'Styles' tab
 - Observe the default styles
 - <u>Optional:</u> Set a preferred style for each facility type (we will use a shortcut)
- 5. Go back to the Settings tab, click the Load button.
 - ✓ Choose From Settings File
 - ✓ Browse to and select SCAG Training\Settings.stg
 - Click OK again to complete the color theme dialog box
- 6. Save the settings (optional, method 1)
 - ✓ Tools → Geographic Utilties → Geographic file
 - ✓ Click Save Settings
- 7. Save the settings (optional, method 2) File –Save As
 - ✓ Save a Map file that you can open later with the settings applied

Color Theme (I	Layer: Master_Network)	X
Settings Styl	es	
General		
Field	FUNC_CLASS	Save
Method	List of Values	Load
# Classes	8 🔻	Recalculate
Trea		
ОК	Cancel Apply Remove	e Customize
	CAMBRIDGE SYSTEM	ATICS





- Labels () can be used to show things including:
 - » Traffic Volumes
 - » Number of Lanes
 - » Centroid Numbers
 - » SED/Land Use Data



Labels can be set differently for different selection sets



The Labels Tab

Labels (Layer: 16r16p_links)
Labels Overlaps Background Callouts
General
Field [AB_AMLANES / BA_AMLANES]
Position Centered above Load
Rotation Along line features
Smart Alignment Stretch Skip Partial Labels
Allow Duplicates Spacing 0 Inches
Limit Lines to Characters
Do not display on the map
Font
@SimSun-ExtB Size 12 3
Agency FB Abaroni Color
Algerian
Andalus Format Default
Angsana Vew Line Height 100 🔷 %
Aparajita
Arabic Transparent Bold Italic
Arial le Shows what Label Text will
OK Cancel Apply Remove

1. Select the field to use for labels

- 2. Set label placement options
 - » Note the "Allow Duplicates" checkbox

3. Set the label style options



The Overlaps Tab

Labels (Layer: abmload_byr)	_ <u>X</u> _
Labels Overlaps Background Callouts	
Overlaps	
Alt. Field None 👻	
Layer Priority 7 (Low)	
Within the layer based on Higher 👻	
values of Length 💌	
Autoscale	
Current Scale 1:611 Clear	
Largest -	
Smallest 👻	
OK Cancel Apply Rem	nove

- Overlapping labels can be allowed if desired
- Different layers can have different priorities
- Autoscale can turn labels on and off automatically



The Background Tab

Labels (Layer: abmload_byr)			
Labels Overlaps Back	ground Callouts		
Туре			
○ None ○ Shadow	Interstate	â	
Halo Frames	Interstate		
Shields			
	Interstate		
	Interstate		
	Business Loop/Spur		
		-	
OK Cancel Apply Remove			

Shadows, halos, frames, or shields can be added to labels to create better looking and more informative maps



Automatic Labels

The Callouts Tab

abels (Layer: abm	load_byr)		x
Labels Overlaps	Background	Callouts	
		- ^	
		Style	▼
		<u>C</u> olor	▼
		-	
		Ŧ	
ОК	Cancel	Apply	Remove

Set the default callout style to use when labels are manually repositioned



Practice 2: Add number of lanes labels

 Open the saved map if needed Use the and zoom-in tool () to zoom in to the area of interest On the top ribbon, click the labels icon () Select the [AB_LANES/BA_LANES] field Change the size and color to match your preference Change the format to have numbers by comma separated Click 'OK' button In training, save the map for future use In training, save the map for future use Size 12 * Color	1. Start with the results from Practice 1	Labels (Layer: Master_Network)
 2. Ose the and 200m-in tool () to 200m in to the area of interest 3. On the top ribbon, click the labels icon () ✓ Select the [AB_LANES/BA_LANES] field ✓ Change the size and color to match your preference ✓ Change the format to have numbers by comma separated ✓ Click 'OK' button In training, save the map for future use Font Size 12 Font Size 12 Color Format Default Gold Ttalic Andation Response Andation Size 12 Format Default Gold Ttalic Color Format Default Format	 Open the saved map if needed 	Labels Overlaps Background Callouts
 3. On the top ribbon, click the labels icon () Select the [AB_LANES/BA_LANES] field Change the size and color to match your preference Change the format to have numbers by comma separated Click 'OK' button In training, save the map for future use Font Font Size 12 Allow Duplicates Spacing 0 Inches Image: Space the map for future use Font Size 12 Format Default Andaus <p< td=""><td>2. Use the and zoom-in tool () to zoom in to the a</td><td></td></p<>	2. Use the and zoom-in tool () to zoom in to the a	
In training, save the map for future use	 Select the [AB_LANES/BA_LANES] field Change the size and color to match your preference Change the format to have numbers by comma separate 	Position Centered above Load Rotation Along line features Smart Alignment Stretch Skip Partial Labels Allow Duplicates Spacing 0 Inches Limit Lines to Characters
OK Cancel Apply Remove	In training, save the map for future use	Font Size 12 Agency FB Aharoni Algerian Andalus Angsana New Angsana New Angsana New Angsana Vec Aparajita Arabic Transparent Arabic Typesetting Arial Color Format Default Line Height 100 Bold Italic E Shows what Label Text wil




Create Scaled Symbol Theme

(also known as bandwidth map)



Scaled Symbol Themes

- Scaled Symbol Themes (*) are often used to:
 - » Display traffic volumes
 - » Display results of a select link or node analysis





Scaled Symbol Themes

Scaled-Symbol Theme (Layer: abmload_byr)
Settings Styles Choose a field U Dua Fields AB_VMT / BA_VMT AB_VHT / BA_VHT AB_FLOW_EA / BA_FLOW_EA AB_FLOW_EA / BA_FLOW_EA AB_FLOW_MD / BA_FLOW_MD AB_FLOW_MD / BA_FLOW_PM AB_FLOW_EV / BA_FLOW_EV AB_PCE_EA / BA_PCE_EA AB_PCE_AM / BA_PCE_AM AB_PCE_MD / BA_PCE_MD Filter
Symbol Sizes Map Wi <u>z</u> ard <u>Manual</u>
Low Value 0 Size 3 High Value 24265 Size 25
OK Cancel Apply <u>R</u> emove

The Settings Tab

Show directional fields only, or all fields

- Select a field to use
- Specify a scale, or let TransCAD specify one automatically




Create Selection Sets



Selection Sets

- Add additional formatting capability
- Useful for analysis and data processing
- Use the Selection Set Toolbox
 - » Select items with a query
 - » Select items by pointing
 - » View the Selection Settings



- One map can contain many selection sets
 - » Show or hide selected items
 - » Format selected items with different colors, styles, and labels



Practice 3: Create selection sets and color and label them

>	Start with the results from Practice 2		
	 Open the saved map if needed 	Master_Network Selection	8
1.	Goto Tools and select 'Selection' or hit F9	▶ ► ► ► ▶ ★ ► ► Selection (997)	s 🛃 🔞
	This will show the selection toolbox shown to the right	Selection (997)	•
	 Click select by condition (¹/₂) to open the query builder 		
	Type in condition: FUNC_CLASS = "Centroid" (option: CONTAIN	NS)	
	 Type the Set Name (Connectors) 	Select by Condition (Dataview: Master_Network)	×
2.	Change the centroid connector lane labels	Enter a Condition	
	 Open selection settings (Selection \rightarrow Settings or	FUNC_CLASS = "Centroid"	ОК
	 Choose Connectors, then click Style 		Cancel
	 Set the color to "default gray) – this allows the color theme to override 		<u>V</u> erify
		Condition Builder Set Name	Clear
	 Click Labels 	Field List Connectors	▼ C10000
	 Set the label to a smaller font size and different color Close the selection settings 	Operator List Selection Method Create Set	<u>S</u> ave ▼ Load
		Function List Other Sets	
\checkmark	TIP: You can make other changes to multiple different solociton sets, or can hide some features altegether.	Values	-
	selection sets, or can hide some features altogether!	Previous Conditions Select from visible features only FUNC_CLASS = "Centroid"	
In tr	aining, save the map for future use		



Data Tables ("Dataviews")



Working with dataviews

- Open a dataview for any existing layer ()
- \rightarrow Open a standalone table with File \rightarrow Open
- Add/Remove fields with Dataview → Modify Table » (or m)
 - » Be careful: Changes are permanent once you click "OK"
- Data can be edited directly in the dataview
 - » Be careful: Changes are saved as you go
- Create formula fields with "Formula Field"
- Right-Click on a column header for more options
 - » Including a formula Fill



Working with Dataviews

Formula Field vs. Add Field & Formula Fill

- » Formula *Fill* adds new data and saves values in the table
- » Formula *Fields* are updated when other values change, but are not stored in the data table
 - Formula fields are stored in a map, dataview (*.dvw), or workspace (*wrk)
- 1. Enter a formula
- 2. Use the Field List to find field names
- 3. Name the formula field

Tip: nz([Field]) converts null values to zero values

Formula (Dataview: OCTA	A_Links)	X
nz(AB_LN_05) + nz(BA_LN_05)		OK
	(1)	Cancel
		<u>D</u> elete
		<u>C</u> lear
		⊻erify
		<u>N</u> ode Fields
- Formula Builder	Formula Fields	Save
Field List	TOT_LANES	Load
Operator List	Previous Formulas	
Function List		•
Values of BA_LN_05 💌		

Practice 4: Add total number of lanes in a NEW FIELD

r

Start with the results from Practice 3

- Open the saved map if needed
- 1. On the top ribbon, click it will open the links layer daataview table
- 2. Use Dataview \rightarrow Modify Table or click
 - ✓ Click 'Add Field'
 - ✓ Name the field "TOT_LANES"
 - You can move the field position using Move Up and Move Down buttons to the right
 - ✓ Click 'OK'
- 3. Go to 'Dataview' window
 - Right click the top part of the 'TOT_LANES' field
 - ✓ Select 'Fill'
 - Select the 'Formula' in the fill method options
 - ✓ Type: nz(AB_LANES) + nz(BA_LANES)
 - Alternatively you can use the formula builder
 - Click 'OK' button.
 - ✓ This fills in two-way number of lanes

Table Specificat	ions								1
Field Name	Туре	Width	Dec	Index	Default	Format	Display Name	*	
AB_EVE_FX_TO	. Real (8 bytes)	10	3			None		_	
BA_EVE_FX_TO	Real (8 bytes)	10	3			None			
AB TOLLV EVE	Real (8 bytes)	10	3			None			
BA TOLLV EVE	Real (8 bytes)	10	3			None			
AB_NT_PM_TO	Real (8 bytes)	10	3			None			
BA_NT_PM_TO	Real (8 bytes)	10	3			None			
AB_NT_FX_TOL	Real (8 bytes)	10	3			None			
BA_NT_FX_TOL	Real (8 bytes)	10	3			None			A
AB TOLLV NT T	Real (8 bytes)	10	3			None			
BA TOLLV NT T	Real (8 bytes)	10	3			None		_	E
TOT_LANES	Real (8 bytes)	10	3			None			_
Field Description									A
Field Descriptior	1								Ľ

Formula (Dataview: Master_Netwo	ork)	×
nz(AB_LANES) + nz(BA_LANES)		ОК
		Cancel
		Delete
		Clear
		Verify
		Node Fields
Formula Builder	Formula Fields	Sum Fields
Field List 👻	Formula 🔹	Save
Operator List 🝷	Previous Formulas	Load
Function List 🝷		-
Values of BA_LANES		



Bonus: Try this example using a formula field instead!

Joining Data



Joining Data

- Layers have an associated data table ()
- Data can be joined (>>) to other tables
 - » Roadway Network + Traffic Assignment results
 - » TAZ layer + Land Use Data
 - » Roadway Network + Lookup Table
 - » More...
- This is how traffic assignment results are viewed in TransCAD



Joining Data

Join 🛛
Settings Options
Create Joined View
Name OCTAM33_TAZ+ZonePABalanced 3
Joining from (left side of join)
Table OCTAM33_TAZ
Field TAZ
Examples 1, 2, 3, 4, 5, 6, 7, 8, 9, 10
To (right side of join)
Table ZonePABalanced
Field ZONE
Examples 1, 2, 3, 4, 5, 6, 7, 8, 9, 10
OK Cancel

- 1. Select the Primary join table
 - » Be careful: Check the Field
- 2. Select the secondary join table
 - » Be careful: Check the Field
- 3. Create a name for the view, or use the default (do this last)

Tip: You can open a file from the join dialog box


– To (right sid	le of join)	
Table	File Open	•
Field	File Open	
Examples		



Practice 5: Join the assignment data to the network layer (Tier 1)

- 1. Open the BCAG Network File (BCAG_Network_2014.dbd)
 - ✓ File → Open, then in the file type dropdown next to 'File name:' select Geographic File(*.cdf,.*dbd) option
 - Browse to the location/fol where the geographic file is located and select the 'BCAG_Network_2014.dbd' and click 'Open' button
- 2. Open the Assignment Data Table
 - ✓ File → Open
 - ✓ File Type Fixed-format Binary (*.bin)
 - Browse to \2014\Outputs\Volumes\Volumes_AM3.bin
- 3. Create a join from Dataview \rightarrow join or
 - Set the left side of the join to Master_Network, field 'ID'
 - Set the right side of the join to Volumes_AM3
 - Set the right side join field to Master_Network, field 'ID1'
 - Click 'OK', then use "info" to review the data
 - ✓ Warning: Do NOT close the joined view!

Join		×
Settings Op	tions	
Create Join	ed View	
Name	Master_Network+Volumes_AM3	
Joining from	m (left side of join)	51
Table	Master_Network	•
Field	ID .	•
Examples	16823, 4, 5, 24, 25, 26, 27, 16763, 29, 30	
To (right si	de of join)	51
Table	Volumes_AM3	•
Field	ID1	•
Examples	1, 2, 3, 4, 5, 6, 7, 8, 9, 10	
	OK Cance	el







Printing Maps (Layouts)





Allow users to create a page to be printed


- » Set paper size
- » Set a specific printer PDF writers work best!
- \rightarrow Created from File \rightarrow New
- Print maps, drawing items, tables, and insets
- Add titles, legends, etc.



Practice 6: Create a Layout with your map

- 1. Start with the results from Practice 5
 - Open the saved map if needed
- 2. Create a new layout using File \rightarrow New or
 - Check the page settings with File \rightarrow Properties or $\circle{2}$
 - Select a printer and page size
 - Set to landsape
 - ✓ Important: Un-check Change size of items when page size changes
- 3. Add your map to the layout using
 - Draw a box to place the map
 - Select Map, check 'Use actual point sizes'
 - Optionally un-check 'Keep map's aspect ratio'
 - Click 'OK'
- 4. Position and edit the legend
 - Use the pointer tool (<a>[]
 - Drag the legend to a good location
 - Double-click to edit legend text and contents
- 5. Add a legend title
 - Use the 'Freehand Text' tool (A), usually at the bottom of the window
 - Drag a box, then type a title
 - ✓ Use the pointer to reposition, double-clicking to edit

Layout Properties
General
Title Untitled
Stored in: None
Printer
Name: Adobe PDF
Status: Ready
Type: Adobe PDF Converter
Where: Documents*.pdf
Comment:
Page Orientation
Size: Letter Portrait
Dimensions:
1 👻 Pages Across 1 👻 Pages Down 💿 Landscape
Change size of items when page size changes
Margins (in inches)
Top 0.250 🚖 Bottom 0.250 🖨 Left 0.250 🖨 Right 0.250 🛓
OK Cancel



More on Networks and Zones



User Variables

Creating your own variables

- » Additional fields can be added to links & nodes layers
- » Field names can contain spaces and numbers, and do not have a practical limit to the number of characters
- » HOWEVER...



User Variables


Creating your own variables

- » It is preferable to:
 - Limit field names to 10 characters
 - Avoid using spaces
 - Avoid starting a field name with a number
- » If these guidelines are followed, compatibility with other GIS programs will be improved
 - Field names that do not follow these guidelines will have truncated or confusing names when exported to a shapefile



Centroids

- Centroids are special nodes that are linked to socioeconomic data
 - » TAZ numbers match the TAZ layer, data tables, and matrices









Learned by Example

- Creating maps
- Adding layers
- Setting layer styles, labels, and themes
- Working with data tables
- Joining Views
- Creating layouts for printing



Highway Assignment



Assignment Results

Basic Volumes

- » Located on the Loaded Network
- » Outputs\Networks\Roads_Loaded_2014dbd
- Volume and Travel Time for:
 - » Each Period(AM, MD, PM, OP)
 - » Total daily

👖 Dataview1 - Master_Network I	
ID	6680
LoadAM_AB	7325.00
LoadAM_BA	-
LoadAM_2Wy	7325.00
LoadMD_AB	9774.00
LoadMD_BA	-
LoadMD_2Wy	9774.00
LoadPM_AB	4125.00
LoadPM_BA	-
LoadPM_2Wy	4125.00
LoadOP_AB	2690.00
LoadOP_BA	-
LoadOP_2Wy	2690.00
Load24_AB	23914.00
Load24_BA	-
Load24_2Wy	23914.00
AM_CAPFAC	2.90
MD_CAPFAC	4.85
PM_CAPFAC	3.70
OP_CAPFAC	7.50
LoadAMPkHr_AB	2416.00
LoadAMPkHr_BA	-
LoadAMPkHr_2Wy	2416.00
LoadPMPkHr_AB	1405.00
LoadPMPkHr_BA	-
LoadPMPkHr_2Wy	1405.00
AB_TTf	1.00
BA_TTf	1.00

Assignment Results

- Detailed Results in a separate table
 - » Join to the network using ID & ID1
 - » By time period or daily
 - » In the \Outputs\Volumes folder



Assignment Results

Detailed Results include:

- » Basics:
 - Total Flow
 - Flow by class (e.g., drive alone, shared ride, truck)
 - Travel time and speed (congested time by period)
- » Extras / Statistics:
 - VMT (called V_Dist_T)
 - VHT
 - Volume to Capacity Ratio ("VOC")
 - PCE Values
- » Select Link / Zone Results
 - Only present if mode was run with
 - Inputs\BCAG_Links.qry



Practice 7: Review Assignment Results

1. Repeat practice 5 result

2. Label the links with the % share of vehicles that are "Drive Alone" (Hint: create a formula field)

Try creating a bandwidth (scaled symbol) theme showing directional volume (hint: Use)



Roadway Network Editing



Warning: Make a backup copy first!

- » There is an "Undo" function in TransCAD
- » Edits are made directly to the network file: You can't close without saving to discard changes

The Undo function in TransCAD 5+ makes network editing less risky

» Network files sometimes become corrupt






Backing up the Roadway Network

Method 1 (recommended):

- » Open the network in TransCAD
- » Use Tools → Geographic Utilities → Geographic File
- » Click **Archive** to save in a zip file

Method 2 (advanced):

- » Close all files in TransCAD
- » Create a zip file with the line layer and route system files
- » Make sure to get <u>all</u> related files





Once you have made a backup, you can:

- » Edit attributes of existing links
- » Change data for a specific year or for multiple years and alternatives
- » Add new links, delete existing links, or realign existing links
- » Add data for a year not yet included in the network





- Edit attributes of existing links
 - » Display settings can assist with editing
- Additional labels and/or themes can be useful
 - » Label # of lanes or other values
 - Show Topology (2)
 to see AB vs. BA



Network Topology

Show topology to identify AB and BA directions





To identify one-way roads, use the DIR field:

- » 0: Two-way travel
- » 1: A → B travel
- » -1: B → A travel



Edit attributes of existing links – Method 1

- » To make most edits, use the information tool (1) and edit text in the form that appears
- » Changes can be undone
 - Each edit action creates an undo point
- » You can select and fill multiple links with the information tool
 - Multiple values can be filled by right-clicking on row names

🖬 Dataview1 - Network Info				
ID	4627	4927	4573	^
Length	0.03	0.02	0.03	
Dir	-1	-1	-1	
STREETNAME	HARRIS	HARRIS	HARRIS	
STREETTYPE	ST	ST	ST	
Dir_10	-1	-1	-1	
FT_10	3	3	3	
AT_10	2	2	2	
AB_LN_10				
BA_LN_10	2	2	2	
CTLMED_10				
SPLM_10	30	30	30	
FFOR_10				
AB_FBAM_10				
BA_FBAM_10				
AB_FBOP_10				
BA_FBOP_10				
SUB_REGION	1	1	1	
Functional_Class	Minor Collectors	Minor Collectors	Minor Collectors	Minor
DOT_ROUTE	0	0	0	~
	0	0	0	> .;



Network Editing Alternate Method

Edit attributes of existing links Alternate Method



- » Use the map editing toolbox (🔏)
- » Use the Edit Line Attributes (👩) button
 - Operation of this tool is similar to using the information button
- » Edits are saved when the green light (5) is clicked
- » Use the red (🗄) light to cancel all unsaved edits
- » The Undo function will undo all edits that are saved at once with the green light



What Fields do I Edit???

- » Facility Type
 - Facility type identifier
- » Lanes
 - Directional number of lanes, by time period
 - Aux. lanes (freeway links only)
- » Direction
- » Area Type
 - Use nearby links as a guide
- » MODE
 - 2 for most links (other values are for transit)
- » Other fields as necessary



Practice: Network Editing


- Open the input network file
- Make a backup copy of this network in a folder called "Backup"
 - » Use Tools → Geographic Utilities → Geographic File and archive the network
 - » Add the date to the backup filename
 - » Edit the original network file
- Try using the different editing approaches to:
 - » Change the facility type
 - » Widen a Road



Practice: Network Editing

- Show Topology on the network
- Change a roadway to represent a different number of lanes in each direction
- Change a different roadway to a one-way road
 - » 0 = Two-Way
 - » 1 = A to B
 - » -1 = to A







Adding new links


- » Use the map editing toolbox (🔏)
- » Add links using Add Line (
 - To work properly, links must be connected at nodes
 - Existing links may need to be split
 - Avoid splitting links if possible
- » Make sure that links are connected by:
 - Saving edits
 - Moving a node around do all of the attached links move with it?
 - Canceling the edit



Adding New Links


- » New links need new data!
- » Copy data from an existing link with similar characteristics
 - Use the Edit Link Attributes (

 button
 - Click/shift-click on the new link(s)
 - Shift-click on the similar old link
 - Right-click on the data for the "old" link and choose "Copy Values"
- » Splitting/Joining Links
 - Check the split/join settings
 - Use the split/join tools (++ ++)
 - New/moved links may be connected at new nodes
 - Check data on split/joined links



Keeping Transit up to date

- » Always add the route system to the network before making edits (link additions, splits, or joins)
- Add the route system from networks\Inputs
 Note: Make sure to choose the Route System file type
- » Make the route system active after every few edits
- » TransCAD will prompt and update the transit network based on your changes









Practice: Network Editing

- Continue editing the input network
- Add, delete, and realign some links
 - » Show topology: Note that the way a new link is created defines its AB direction
- Copy link values from an old road to newly created links
- Split and join links
 - » look at the data that appears on each half
 - » Look at the network editor settings (🔀)



Things to keep in mind:

- » When splitting links, make sure the data on both pieces still makes sense
- » When adding new roadways, adjust centroid connectors if necessary
- » Adding detail or making corrections?
 - You may need to make edits to base and forecast networks



Advanced Topics



Advanced Topics

Matrix Files and OD Tables

- » Matching matrix files to zones/centroids
- » Visualizing trip table data
 - Desire Lines
- Setting up Select Link and Zone Anlaysis
 - » Creating a query file
 - » Running assignment only with select analysis activated
- Routable Networks
 - » Creating and updating a ".net" Network
 - » Interactive pathbuilding

Basic Scripting

- » Batch Recorder
- » Simple Macro Creation



Thank You!

